


Connect cardboard as simply as righty tighty, lefty loosey.

Connects up to three layers of corrugated cardboard.



Steel blade with no sharp edges to swiftly saw cardboard.



Perforate lines to sculpt like a pro.



Connects up to six layers of corrugated cardboard.

